



อีซี ปืนยิงกาวไฟฟ้า - กาวแท่ง - เทปกาว2หน้า



JOER
Production Since 1982

FOR YOUR SAFETY

- Working safely with this unit is possible only when the operating and safety instructions are read completely and the instructions contained therein are strictly followed.
- If the cabinet is damaged or cut through while working, do not touch the cable but immediately pull the main plug. Never use the unit with a damaged cable.
- Before each use of the unit, check the cable and plug if damage is detected. Do not use the unit when repairs performed only by a qualified technician. Never open the unit yourself.
- Gluing: Danger of burning! The glue and the nozzle tip are heated to 200°C. Do not allow the hot glue to come into contact with persons or materials. If glue touches the skin, immediately hold the spot for some minutes under a stream of cold water. Do not try to remove the glue from the skin.
- Never lay flat in use.
- The unit must not be damp and must also not be operated in damp surroundings.
- Always direct the cable to the rear away from the unit.
- Children may only use the unit under the supervision of adults.
- JOER is able to ensure flawless functioning of this unit if the original accessories intended for it are used.

BEFORE USE

- Screw the nozzle onto the gun, insert the support.
- To put into operation, insert the plug into the main receptacle.
- Press the gun on the support stand.
- Allow the gun to heat up for approx. 30s before beginning work. To switch off, pull the main plug.
- Allow the unit to cool completely before storing. The hot nozzle can cause damage.
- As the result of heat exchange the glue gun can also be used after it has heated up without connected to the mains.

WORKING INSTRUCTIONS

- The surface to be glued must be clean, dry and free of grease. Roughen smooth surfaces before gluing, insert the glue stick.
- Press the lead trigger after applying the glue.
- Press the surfaces to be glued together immediately.

ENVIRONMENTAL PROTECTION

- Recycle raw materials instead of disposing as waste.
- The unit, accessories and packaging should be submitted for environmental-friendly recycling.

MAINTENANCE AND CLEANING

- Before any work on the unit, pull the main plug.
- Always keep the unit clean so that it functions properly and accurately.

The packaging of the product color may vary different from the product in hand.

MADE IN CHINA

ปืนกาวไฟฟ้าเล็ก S-603 20w

บรรจุ 24 อัน/ลัง

ปืนกาวไฟฟ้าใหญ่ S-806 60w

บรรจุ 12 อัน/ลัง

****หัวทองเหลือง****



กาวแท่ง ใส่ปืนยิงกาว

#909

แท่งเล็ก

#919

แท่งใหญ่

บรรจุ 24 กก/ลัง



เทปกาวสองหน้าบาง

6 มม

12 ม้วน/แพ็ค, 720ม้วน/ลัง

12 มม

6 ม้วน/แพ็ค, 360ม้วน/ลัง

18 มม

4 ม้วน/แพ็ค, 240ม้วน/ลัง

24 มม

3 ม้วน/แพ็ค, 180ม้วน/ลัง